

## ✂ Maintenance

✂ In order to lengthen the life time, single using time is better not more than 20 minutes
✂ In order to lengthen the life time, clean the body, filter and dustbag after use.
✂ Twine the power cord well, put accessories in slot
✂ Clean the dirty water after using to prevent the rusting or corrosion of barrel.
✂ Clean the surface of vacuum cleaner with dry cloth to prevent water into vacuum cleaner caused short circuit even vacuum cleaner burning

## ✂ Common fault guides

Fault	possible reason	handling method
Motor failure	<ol style="list-style-type: none"> <li>1. check power plug if it is wired up properly?</li> <li>2. check power socket if it is electricity?</li> <li>3. Check the switch if it is turned on</li> </ol>	<ol style="list-style-type: none"> <li>1. Repair the plug into the socket</li> <li>2. Make sure the power socket is electricity</li> <li>3. Turn on the switch</li> </ol>
Suction abate	<ol style="list-style-type: none"> <li>1. check brush, hose and telescopic tube if they are blockage?</li> <li>2. check dustbag if it is with full dust?</li> <li>3. Check the filter if it is blocked</li> </ol>	<ol style="list-style-type: none"> <li>1. Clean the blockages</li> <li>2. Clean the dustbag</li> <li>3. Clean the filter</li> </ol>
Hot air outlet	<ol style="list-style-type: none"> <li>1. check the suction if it is normal</li> <li>2. check the using time if it is more than 20 minutes</li> </ol>	<ol style="list-style-type: none"> <li>1. The hot air from vacuum cleaner is caused by motor heat conducting. It's common, pls continue to use.</li> <li>2. pls turn off to rest 20 minute before use again.</li> </ol>

## ✂ Product explosion view and spare parts list

